

## Coupling of 301 Series Windows, Including French doors

All Sovereign windows can be coupled together or combined to form a single window combination by the use of coupling strips. In the case of the 301 Series Windows and French Doors this can be achieved by the following steps

The procedure is to fit the coupling strips supplied to the outer groves along the outside of the frame. The windows or door are then aligned and with a rubber mallet taped together to form the required configuration.



Step 1- Tap the coupling strip into the groove



Step 2 – Tap the second strip into position



Step 3- End view of couplings



Step 4- Windows coupled together

---

### Sydney office:

Sovereign Windows & Doors Pty Limited  
Unit 4 / 185 Briens Road  
Northmead NSW  
Australia 2152  
ABN: 76 120 690 959



Phone: 02 - 9630-8190  
Fax: 02- 9890-7133



Email: [sales@sovereignwindows.com.au](mailto:sales@sovereignwindows.com.au)  
Web site: [www.sovereignwindows.com.au](http://www.sovereignwindows.com.au)

**HIA members**   
the best in the business